


DS137F/DS147F

DS137F

DS147F

Rear Axle Suspension System
for Ford SuperDuty F550
based Ambulance, Transit Bus
and Limo



Operator Manual

D10882 Rev Y 12/2018

Contents

CONTENTS	2
INTRODUCTION	3
SUSPENSION RATING	3
SERIAL NUMBER TAG INFORMATION	3
VEHICLE TOWING AND JACKING INFORMATION	3
TORQUE SPECIFICATIONS	4
SYSTEM OPERATION	5
System Start Up:	5
ON/OFF Button:	5
Warning Light:	5
Ride Mode Adjustment:	5
Ride Height Adjustment:	5
Depressurizing the System	6
Bleeding the System	7
Calibrating the Steering Sensor Only	7
Calibrating the System	7
Checking Fluid Level	8
Checking Fittings for Leaks	8
SERVICE INTERVALS	9
Once Daily or Before Each Shift of Usage	9
Initial 1,000 mile (1,600 km) Inspection	9
Routine Maintenance 25,000 miles (40,000 km) or 6 month maximum Interval	9
MAINTENANCE RECORD.....	10
TROUBLESHOOTING	11
Issues with Vehicle Raising/Pump	11
Issues with Vehicle Lowering/Dump Valve.....	11
Issues with One Corner Not Leveling Properly	12
Issues with Height Sensors.....	12
Issues with Ride/Handling	12
Issues with Steering Sensor.....	12
Issues with Vehicle Speed Signal	14
Issues with Vehicle Brake Signal	14
Issues with Door Switch.....	14
Issues with Vehicle Ignition Signal	14
Issues with Vehicle Park Signal.....	14
Issues with Driver Interface	14
Issues with Power Module	15
Issues with Strut Assembly	15
Issues with Secondary Volume Assembly.....	16
PARTS LIST INFORMATION.....	17
ABBREVIATIONS	17
PART IDENTIFICATION	17
ELECTRICAL SCHEMATICS	28

Introduction

This manual provides operating information for the LiquidSpring CLASS® DS120R/DS135R series of rear axle suspension systems for the Ram 4500/5500 Cab Chassis.

The system provides the following performance benefits:

- Reduced Impact Harshness
- Improved Road Isolation
- Improved High-Speed Stability
- Improved Handling Response
- Better Control of Body Ride Motions
- Maintained Optimized Ride Height

Throughout this manual, important product information is indicated. These terms are defined as follows:

NOTE: Includes additional information to enable accurate and easy performance of procedures.

IMPORTANT: Includes additional information that if not followed could lead to hindered product performance and/or product failure.

CAUTION: A caution indicates procedures that must be followed exactly. Damage to equipment or suspension components and personal injury can occur if the procedure is not followed.

WARNING: A warning indicates procedures that must be followed exactly. Serious personal injury can occur if the procedure is not followed.

These instructions cover the following models:

Model	Application
DS137F-A	13,660 GAWR F550
DS147F-B2	14,706 GAWR F550

LiquidSpring LLC reserves the right to modify the suspension and/or procedures and to change specifications at any time without notice and without incurring obligation.

Suspension Rating

Model	Suspension Rating
DS137F-A	13,660 lbs
DS147F-B2	14,706 lbs

WARNING: Overloading suspension system may result in abnormal handling characteristics and premature wear of components.

Serial Number Tag Information

The suspension model, serial number, and maximum axle capacity are found on an aluminum tag that is riveted to the Left Hand Suspension Hanger as shown in Figure 2. This information will aid you when contacting the chassis manufacturer or LiquidSpring LLC.



Figure 1. Suspension Identification




Figure 2. Serial Number Tag Location

Vehicle Towing and Jacking Information

Before attempting any type of towing procedures, contact the OEM/Coach Builder for instructions.

NOTE: Before towing vehicle, check with local authorities, such as Department of Transportation, for permissible towing methods. Some states do not permit towing vehicles by chains or towing straps.

Do not attach tow apparatus (hooks, chains, straps, etc.) to the suspension components.

WARNING: Attaching towing equipment to improper locations and failure to utilize OEM/Coach Builder recommended towing methods could result in one or more of the following:

- Damage to the suspension and/or vehicle,
- Loss of vehicle control,
- Possible disconnect from the vehicle.

WARNING: Do not apply jack to bottom of front hanger or other suspension components. Applying a jack to improper locations can result in damage to the suspension and/or vehicle and severe personal injury.

Torque Specifications

Most of the fasteners used in this suspension are graded fasteners. These fasteners have the strength and hardness properties required for their particular function. If replaced, they must be replaced with fasteners of the same grade, size, and form as the original in order to prevent failure.





Figure 3. Identification of fastener grades.

Description	Size	Grade	Torque Specification	
			Lb-ft	Nm
Axle Clamp Attachment Nuts	1/2-13	C	86-105	117-142
Axle Clamp Attachment Screw	1/2-13	C	86-105	117-142
Axle Clamp Brake Line Screw (OEM Reuse)	M8-1.2	N/A	18	25
Axle Clamp U-Bolt Flange Nuts	3/4-16	C	See Procedure	
Bleed Screws	3/8-24	N/A	13-18	1-2
Bridge, Brake Line Securing Nut	1/4-20	C	10-12	14-16
Bridge Mount Nuts	5/8-11	C	172-210	233-285
Bridge U-Bolt Flange Nuts	5/8-18	C	180	244
Control Arm Flange Nuts	1-8	G	600	813
Cross Member Reinforcement Nuts	1/2-13	C	86-105	117-142
Hanger Mount Bolts (OEM Reuse)	M14-2	10.9	120-145	163-197
Hanger Mount Nuts	5/8-11	C	172-210	233-285
Height Sensor Linkage Ball Stud Nut	5/16-18	C	14-17	19-23
Height Sensor Mount Nuts	5/16-18	C	14-17	19-23
Hose Connections, -10	7/8-14	N/A	36-63	4-7
Hose Connections, -4	7/16-20	N/A	12	1
Jounce Stop Bolt	M10-1.5	10.9	42	57
Jounce Stop Seat Screw	1/2-13	C	86-105	117-142
Power Module Manifold Bracket Screws	3/8-16	8	39	53
Power Module Reservoir Support Screws	#10	N/A	Snug Only	
Power Module J-Bolt Nut	3/8-16	5	28	38
Power Module Mount Nuts	3/8-16	8	35-43	47-58
Steering Sensor Bracket Nuts (OEM Reuse)	M14-2	10.9	120-145	163-197
Steering Sensor Linkage Ball Stud	5/16-18	N/A	14-17	19-23
Steering Sensor Linkage Bracket U-Bolt Nuts	1/4-20	2	60-85 in-lbs	7-10
Steering Sensor Mounting Screws	5/16-18	8	14-17	19-23
Strut Lower Mount Flange Nuts	1-8	G	250	339
Strut Upper Mount Flange Nuts	1-8	G	600	813
Track Rod Frame Mount Nuts	1/2-13	C	86-105	117-142
Track Rod Nuts	5/8-11	C	172-210	233-285
Upper Strut Mount Bracket Nuts	5/8-11	C	172-210	233-285
Volume Mount Clamps	5/16-24	N/A	240 in-lbs	27
Volume Mount Nuts	3/8-16	C	35-43	47-58

System Operation



System Start Up:

- In most instances, the suspension system can be left alone to operate automatically.
- After startup, all the indicator lights will flash on for 1-2 seconds, and then the Green Ride Height Indication LED and Green Ride Mode Indication LED will light to show the current Ride Mode and Ride Height.
- The four yellow LED's will light up if the steering wheel is approximately 10°-20° each side of straight ahead, but will not light up when steering wheel exceeds 20° from center. If the vehicle is steered straight ahead and the four yellow LED's are not lit (and the red warning LED is not lit) see Calibrating the Steering Sensor Only.
- When the steering wheel is turned more than 20° off center, the four Yellow Steering Centering Indication LED will not be lit.

ON/OFF Button:

Pressing the ON/OFF button will disable the suspension system (turns off all indicator lights) or enables the system (turns on all indicator lights). It is recommended leaving the system ON at all times.

IMPORTANT: After turning the vehicle ignition off, the suspension system will remain powered for 1 hour before shutting off.

Warning Light:

If the Red LED warning light is continuously illuminated along with one or more of the other indicator lights, please refer to the **Troubleshooting** Section on page 11.

Ride Mode Adjustment:

Press the UP/DOWN arrow buttons to change the ride mode between SPORT, NORMAL, and COMFORT. The Green indicator light will show the set mode.

- **Comfort Mode** provides a smooth, soft ride. Use for normal city and highway driving.
- **Sport Mode** provides more “feel” or response to the road conditions. Use where road conditions or personal preference demand more control.
- **Normal Mode** is a balance between Comfort and Sport. Use where more control than Comfort is desired, but better ride than Sport.

The setting can be changed at any time. Based on road conditions, steering wheel angle, and the vehicle speed, the system automatically adjusts to provide the best handling while providing a smooth ride. All three settings will feel similar on a smooth road.

Ride Height Adjustment:

Press the UP/DOWN arrow buttons to change ride height from NORMAL to HIGH (body up) or LOW (body down).

- A solid green LED will indicate the selected height. A flashing green LED will indicate the current height and that height adjustment is

occurring. When a single solid green LED is lit, the selected height has been achieved.

- Two solid green LEDs will be lit if the current height is not the selected height and height adjustment is not occurring.
- If LOW or HIGH heights are selected while the vehicle is traveling at less than 10 mph or stopped, the suspension height is either lowered or raised.
- If LOW or HIGH heights are selected while the vehicle is traveling at greater than 10 mph, the suspension will ignore the selected height and remain in NORMAL height unless the vehicle speed goes below 10 mph within 2 minutes of selecting the height. In this instance, the NORMAL height green LED will flash and the selected height green LED will be lit solid until the speed goes below 10 mph within 2 minutes of selecting the height. If the vehicle speed doesn't go below 10mph within the 2 minute period, the suspension will remain in NORMAL height indicated by only the NORMAL height green LED lit solid.
- If LOW height is selected and the ignition is turned off before LOW height is achieved, the system will continue to lower to LOW height. When LOW height is selected the system will monitor and maintain the kneeled position by only lowering as needed for 1 hour after the ignition is turned off.
- If HIGH height is selected and the ignition is turned off before HIGH height is achieved, the system will stop adjusting ride height. When HIGH height is selected the system will monitor and maintain the current position by only lowering as needed for 1 hour after the ignition is turned off.
- The door switch function (if equipped) is disabled when the driver display LOW or HIGH height is selected before the door is opened on vehicles equipped with a door switch for kneeling.

IMPORTANT: While parked for an extended time with the vehicle and/or suspension system turned off, suspension ride will change with temperature change. Increases in ambient temperature or parking in direct sunlight can cause the suspension ride height to increase. As temperature lowers, the suspension ride height can decrease.

Depressurizing the System

1. Turn the ignition key to "Run" and ensure that the LiquidSpring driver display LEDs light up and that the red "Warning" LED is not lit. If the red

"Warning" LED is lit, proceed to the Trouble Shooting Section.

WARNING: Do not run vehicle in an enclosed building without adequate ventilation or without ducting exhaust fumes outside. Operation of a vehicle inside an enclosed building can lead to serious injury or death.

1. Press and release the Red ON/OFF button on the driver display. All LEDs on the driver display should go out.
2. Press and release the Red ON/OFF button again. The LEDs on the driver display should all flash and then only the four yellow arrow LEDs, one green ride mode indicator LED, and one green ride height indicator LED should remain lit.
3. Press and release the HEIGHT DOWN arrow button to lower the vehicle to the LOW height.
4. Press and hold the HEIGHT DOWN arrow button for approximately 2 minutes.
5. Release the HEIGHT DOWN arrow button.
6. Press and release the ON/OFF button to disable the system.
7. Turn off the vehicle ignition.

If any of the hydraulic connected components is to be removed and serviced, it is recommended to also follow the following steps:

8. Locate 3/16" ID PVC Tubing (not included with kit). Note: Alternatively, a bleed kit similar to the Actron 7840 Bleed Kit or Lisle 19200 Brake Bleeding Kit (found at Sears) can be used.
9. Attach the PVC tubing to one of the upper bleed screws on the Left Hand Secondary Volume Assembly and place the other end in a bucket.




Figure 3. Bleed screw locations.

10. Open the bleed screw slightly to relieve any residual pressure.
11. After pressure is relieved, close the bleed screw and torque to 13-18 ft-lbs.

Notes:

- Jacking up the chassis of a lowered, depressurized chassis will cause a slight vacuum in the system and minimize fluid loss while disconnecting hoses.
- For service of non-hydraulic connected suspension components, the suspension system can be first raised to the HIGH height, appropriate jack stands placed under the chassis, then depressurized as listed above lowering the chassis onto the jack stands.

Bleeding the System

1. Verify system is turned OFF by either pressing the ON/OFF button on the driver interface until the lights are turned off or turning the ignition off.
2. Locate 3/16" ID PVC Tubing (not included with kit). Note: Alternatively, a bleed kit similar to the Actron 7840 Bleed Kit can be used.
3. Attach the PVC tubing to one of the upper bleed screws on the Left Hand Secondary Volume Assembly and place the other end in a bucket.




Figure 4. Bleed screw locations.

4. Open the bleed screw slightly.
5. After air bubbles are no longer present, close the bleed screw and torque to **13-18 ft-lbs.**
6. Repeat with remaining bleed screws. Note: the system may need to be powered on and allowed to re-pressurize.
7. Repeat with other side.

Calibrating the Steering Sensor Only

Note: The yellow lights only light up when the steering sensor indicates the center location. They will not be lit outside of 10°-20° off center.

IMPORTANT: The LiquidSpring CLASS® system includes an automatic self-centering routine. In conditions such as driving on highway with significant side wind, the yellow lights may temporarily not be lit when the steering wheel is exactly centered. Rotate slowly from center to full steering stop, then repeat the opposite direction. If the yellow lights momentarily light up during the travel in one

or the other direction, the system is operating normally and the steering sensor does not need to be manually re-centered. Continue operating normally.

If the yellow lights do not light up at all during turning the steering wheel, following the instructions below.

1. Verify that the front wheels are steered straight ahead.
2. To begin the calibration, turn the ignition key to "Run" and ensure that the LiquidSpring driver display lights up and that the red "Warning" LED is not lit or flashing.

WARNING: Do not run vehicle in an enclosed building without adequate ventilation or without ducting exhaust fumes outside. Operation of a vehicle inside an enclosed building can lead to serious injury or death.

3. Press and release the Red ON/OFF button on the driver display. All LEDs on the driver display should go out.
4. Press and release the Red ON/OFF button again. The LEDs on the driver display should all flash and then only the four yellow arrow LEDs, one green ride mode indicator LED, and one green ride height indicator LED should remain lit.
5. Press and hold both Ride Height Adjustment Buttons simultaneously until the SPORT, COMFORT, HIGH, and LOW green LED's begin to flash.
6. As soon as the four green LED's begin to flash, press the ON/OFF button to stop the process.
7. Verify that the four yellow arrow LED's are lit.
8. Steering calibration is completed.

Calibrating the System

IMPORTANT: Proper calibration of the system must be conducted with the vehicle loaded to the as delivered condition with body installed. For calibration on an empty chassis cab, LiquidSpring recommends weight be added to the frame approximately equal to the planned body to allow for proper bushing deflections.

Note: The LiquidSpring Calibration routine will automatically determine maximum and minimum suspension ride height. Based on those ride heights, the system will determine the correct normal design ride height. The calibration system will also calibrate the steering sensor.

1. Verify that the front wheels are steered straight ahead.
2. Lower the vehicle to the ground and remove any jack stands and any other obstructions from under the vehicle.

3. To begin the calibration, turn the ignition key to “Run” and ensure that the LiquidSpring driver display lights up and that the red “Warning” LED is not lit or flashing.

WARNING: Do not run vehicle in an enclosed building without adequate ventilation or without ducting exhaust fumes outside. Operation of a vehicle inside an enclosed building can lead to serious injury or death.

4. Press and release the Red ON/OFF button on the driver display. All LEDs on the driver display should go out.
5. Press and release the Red ON/OFF button again. The LEDs on the driver display should all flash and then only the four yellow arrow LEDs, one green ride mode indicator LED, and one green ride height indicator LED should remain lit.
6. Press and hold both Ride Height Adjustment Buttons simultaneously until the SPORT, COMFORT, HIGH, and LOW green LED’s begin to flash. The suspension system will begin to rise to the full high position, and then lower to the full lowered position.
7. After the system completes the calibration routine, the suspension will return to the original ride height.
8. Turn off the ignition for at least 3 minutes. Note: The suspension system will not use the calibrated ride height settings until power has been cycled.

Note: Pressing the red ON/OFF button on the driver display does not cycle power to the LiquidSpring suspension system, but only will enable/disable the system.

9. Turn the ignition back to Run,.
10. Press and release the Red ON/OFF button on the driver display. All LEDs on the driver display should go out.
11. Press and release the Red ON/OFF button again. The LEDs on the driver display should all flash and then only the four yellow arrow LEDs, one green ride mode indicator LED, and one green ride height indicator LED should remain lit.
12. Calibration is now completed.

Checking Fluid Level

1. Turn the ignition key to “Run” and ensure that the LiquidSpring driver display LEDs light up and that the red “Warning” LED is not lit. If the red “Warning” LED is lit, proceed to the Trouble Shooting Section.

WARNING: Do not run vehicle in an enclosed building without adequate ventilation or without ducting exhaust fumes outside. Operation of a vehicle inside an enclosed building can lead to serious injury or death.

2. Press and release the Red ON/OFF button on the driver display. All LEDs on the driver display should go out.
3. Press and release the Red ON/OFF button again. The LEDs on the driver display should all flash and then only the four yellow arrow LEDs, one green ride mode indicator LED, and one green ride height indicator LED should remain lit.
4. After the suspension system stops leveling, check the fluid level in the reservoir. If low, fill to the indicated line.




Figure 5. Final fill fluid level.

5. To add fluid, remove filler/breather cap on reservoir.
 6. Locate a container of Compressible Fluid.
 7. Add fluid to the reservoir until the fluid level is within the band shown in Figure 5.
- Note. LiquidSpring Compressible Fluid is shipped in 1 gallon containers compatible with hand pumps such as Autotec 57429.
8. Replace filler/breather cap and retighten.

Checking Fittings for Leaks

WARNING: The system operates under high fluid pressure (up to 3500 psi). Do not attempt to locate leaks by feeling with hands or any part of the body. High pressure fluids can penetrate the skin and cause severe tissue damage.

1. While system is at ride height and pressurized, visually examine fittings and hose connections for any source of leaks. Do not use hands to search for leak. If the source of the leak is a fitting or other component, depressurize the system and repair or replace as needed.

2. Tighten hose nuts if the leak is coming from the connection between the hose nut and a fitting. Depressurize the system before tightening anything. Replace hose if the leak is coming from anywhere else on the hose.

WARNING: Never tighten a hydraulic fitting or hose under pressure. Always depressurize the system before adjusting fittings and hoses.

3. Clean all fluid from hose and fittings to visually identify any leaks.

IMPORTANT: Over-tightening hoses and fittings can damage components and lead to leaks.

See Installation Manual for additional instructions.

Service Intervals

Once Daily or Before Each Shift of Usage

- Check the suspension system to be sure it is fully operational.
 - After starting vehicle, verify all LED's on the driver display flash briefly, then the Green Ride Height and Ride Mode LED's are lit and the Red Warning LED does not stay on or flash.
 - Verify the four Yellow LED's are lit when the steering wheel is centered.
 - Verify that the system is at NORMAL ride height, with a steady green LED.
 - If the Driver Display indicates a blinking ride height LED, allow the system to complete leveling as indicated by a steady green LED.
 - If LOW or HIGH height is shown with a solid green LED, use the arrow buttons to raise or lower the suspension to NORMAL height.
 - Refer to *Ride Height Adjustment*: Section.
- Visually inspect struts, hoses, and fittings for signs of leakage.
 - For leakage resulting in fluid pooled on the floor greater than 1" in diameter, it is recommended to service the system immediately.
 - For signs of leakage or weeping that results in wetness on components or a single drop, it is recommended to monitor the leak and schedule repair service accordingly.

Initial 1,000 mile (1,600 km) Inspection

- Inspect bolts and nuts at the control arm pivots to assure they are properly torqued.
- Inspect u-bolts to assure they are properly torqued.
- Thoroughly inspect all hydraulic connections for signs of leakage.
- Inspect reservoir fluid level.

Routine Maintenance 25,000 miles (40,000 km) or 6 month maximum Interval

- Check all suspension components for any signs of damaged/broken components, looseness, or wear.
- Inspect bolts and nuts at the control arm pivots to assure they are properly torqued.
- Inspect u-bolts to assure they are properly torqued.
- Thoroughly inspect all hydraulic connections for signs of leakage.
- Inspect reservoir fluid level.

Maintenance Record

Date of Purchase		Name and Address of Dealer	
Model of Vehicle		Vehicle Identification Number (VIN)	
Suspension Model Number		Suspension Serial Number	
Date	Mileage	Service Performed	

Troubleshooting

The LiquidSpring CLASS® system includes on-board diagnostics to assist in pin-pointing potential issues. When a fault in the system occurs, the red warning light on the Drivers Interface will light along with one or more of the other lights on the interface.

Driver Interface Lights	Condition	Cause	Correction
Warning + RIDE: SPORT	Battery Voltage in excess of 16VDC	Vehicle charging system providing incorrect voltage.	Inspect and replace as necessary.
		LiquidSpring system not connected to 12VDC electrical system	Inspect and replace as necessary
Warning + RIDE: NORMAL	Pump Motor runs in excess of 3 minutes	See <i>Issues with Vehicle Raising/Pump Section</i>	See <i>Issues with Vehicle Raising/Pump Section</i>
Warning + RIDE: COMFORT	Battery Voltage below 9 VDC	Vehicle charging system providing incorrect voltage	Inspect and replace as necessary
		80A fuse blown / Loss of battery voltage on circuit W25	Inspect / Repair Replace as necessary
Warning + HEIGHT: HIGH	Issue with Right Hand Height Sensor	See <i>Issues with Height Sensors Section</i>	See <i>Issues with Height Sensors Section</i>
Warning + HEIGHT: NORMAL	System kneels in excess of 3 minutes without suspension movement	See <i>Issues with Vehicle Lowering/Dump Valve Section</i>	See <i>Issues with Vehicle Lowering/Dump Valve Section</i>
Warning + HEIGHT: LOW	Issue with Left Hand Height Sensor	See <i>Issues with Height Sensors Section</i>	See <i>Issues with Height Sensors Section</i>
Slow or Fast Blinking Warning Light	Driver Interface cannot communicate with ECU.	See <i>Issues with Driver Interface</i>	See <i>Issues with Driver Interface</i>

Issues with Vehicle Raising/Pump

Condition	Cause	Correction
Vehicle Leveled, Pump continues to run	Pump motor shorted out.	Contact LiquidSpring for further instructions.
	Software issue	Turn off ignition, wait 30 seconds, restart vehicle.
	Excessive noise in height sensor	See <i>Issues with Height Sensors</i>
Vehicle Not Leveled (or Raised), Pump runs	Reservoir fluid level low	Fill reservoir to specified level.
	Hydraulic leak in system	Check for fluid leaks and repair or replace.
	Vehicle overloaded	Check vehicle loading and correct.
	Air in pump	Check fluid level in reservoir and fill accordingly. Fully depressurize system and restart leveling.
	Internal leak in power module	Replace power module.
	Height sensor error	See <i>Issues with Height Sensors</i>
Vehicle Not Leveled (or Raised), Pump does not run	System not turned on.	Turn system on.
	Blown fuse	Check system fuses
	Loss of electrical power	Check wiring between power module and battery.
Pump runs for short time then stops	Motor controller over temperature	Contact LiquidSpring for further instructions.
Pump runs intermittently	Loose connector or wiring	Check wiring harness connections and battery connections. Repair as necessary.

Issues with Vehicle Lowering/Dump Valve

Condition	Cause	Correction
Vehicle does not lower (kneel).	System not turned on	Turn system on
	Blown fuse	Check system fuses and replace as necessary
	Obstacle under vehicle frame	Remove obstacle
	Wiring harness disconnected	Check wiring harness connections and reconnect
	Loss of electrical power	Check wiring between power module and battery
	Power module filters plugged	Contact LiquidSpring for further instructions
	Internal power module blockage	Contact LiquidSpring for further instructions

Vehicle slow lowering (kneeling)	Partial internal power module blockage	Contact LiquidSpring for further instructions
----------------------------------	--	---

Issues with One Corner Not Leveling Properly

Condition	Cause	Correction
One side will not raise or lower	Internal power module blockage	Contact LiquidSpring for further instructions
	Low voltage	Check battery voltage.
	Wiring harness disconnected	Check wiring harness connections and reconnect
	Obstacle under vehicle frame	Remove obstacle
	Power module filters plugged	Contact LiquidSpring for further instructions
	Height sensor error	See <i>Issues with Height Sensors</i>
One corner raises and lowers slower than other corners	Internal power module blockage	Contact LiquidSpring for further instructions
	Filter partially clogged	Contact LiquidSpring for further instructions

Issues with Height Sensors

Condition	Cause	Correction
Vehicle or corner stops leveling at incorrect height	Damaged height sensor and/or linkage	Inspect height sensor components. Replace as necessary.
	Incorrect calibration	Recalibrate vehicle – see System Operation section.
	Incorrect height sensor installation	Inspect height sensor components and correct.
Corner height where leveling stops is inconsistent	Sensor or Linkage loose	Inspect installation of height sensor and linkages and tighten if necessary
	Loose connector / wire	Inspect wiring between sensor and power module for loose connection
Vehicle will not level - no height sensor signal	Height Sensor wiring shorted, broken, or disconnected	Inspect wiring between sensor and power module.
	Malfunction in Sensor	Replace sensor.
No Height Sensor Signal change while driving	Linkage broken/disconnected	Inspect installation of height sensor and linkages. Correct and/or replace.

Issues with Ride/Handling

Condition	Cause	Correction
Vehicle rolls side to side excessively	System inactive (Drivers interface dark)	Turn system on (press On/Off button)
	No electrical power to system	Inspect and replace as necessary
	Strut bushings worn	Inspect and replace as necessary
	Control arm bushings worn	Inspect and replace as necessary
	Sway bar bushings worn	Inspect and replace as necessary
	Strut mounting loose	Inspect and replace as necessary
	Rate Valve wiring shorted, broken, or disconnected	Inspect wiring and correct/replace as necessary.
	Voltage to Rate Valve solenoid too low	Check battery voltage.
	Rate Valve Poppet Jammed open	Contact LiquidSpring for further instructions
	No vehicle speed signal	See <i>Issues with Vehicle Speed Signal</i> section.
Excessive stiffness when on flat, straight road	Short to Rate Valve	Check wiring between rate valve (on secondary volume) and power module for signs of shorts. Replace as necessary.
	Wiring to Rate Valve incorrect	Inspect wiring and correct as necessary

Issues with Steering Sensor

Condition	Cause	Correction
No steering signal (reduced roll control when cornering)	Steering sensor wiring broke or incorrect.	Inspect wiring to steering sensor and correct as necessary.
	Steering sensor malfunction	Replace sensor
	Steering sensor not installed correctly	Inspect installation and correct as necessary
Yellow lights on driver display not lit when steered straight ahead.	Zero point of steering sensor incorrect.	See <i>Calibrating the Steering Sensor Only</i> .
Intermittent steering sensor signal	Loose connector / wire	Check wiring between Steering sensor and Power module for loose connection.

Issues with Vehicle Speed Signal

Condition	Cause	Correction
System leveling excessively while driving.	Speed Sensor wiring shorted, broken, or disconnected	Inspect wiring and repair/replace as necessary
	Speed signal malfunction	Replace OEM speed sensor. See OEM service manual.
Intermittent speed sensor signal	Loose connector / wire	Check wiring between Speed sensor and Power module for loose connection.

Issues with Vehicle Brake Signal

Condition	Cause	Correction
Vehicle will not level	Brake signal wire not correctly tapped.	Inspect wiring and repair/replace as necessary.
	Brake switch malfunction	Replace OEM speed sensor. See OEM service manual.
Intermittent leveling	Loose connector / wire	Inspect wiring and repair/replace as necessary.

Issues with Door Switch

Condition	Cause	Correction
Vehicle will not kneel when rear door opened	Short or break in wiring between door switch and power module.	Inspect wiring and repair/replace as necessary.
	Door switch malfunction	Inspect door switch and repair/replace as necessary
Vehicle kneels whenever speed below 5mph	Short or break in wiring between door switch and power module.	Inspect wiring and repair/replace as necessary.
	Door Switch out of adjustment	Check installation of door switch and adjust as necessary
	Door switch malfunction	Inspect and replace per body builder instructions.
Intermittent door switch signal	Loose connector / wire	Inspect wiring and repair/replace as necessary.

Issues with Vehicle Ignition Signal

Condition	Cause	Correction
System does not turn on (no leveling or stiffness control)	No ignition signal to controller or driver interface	Inspect wiring and repair/replace as necessary.
	Ignition "sensor" malfunction	Inspect and replace per OEM service manual.
System does not turn off once ignition switched off	Signal side short to battery	Inspect wiring and repair/replace as necessary.
	Ignition "sensor" malfunction	Inspect and replace per OEM service manual.
System intermittently works	Loose connector / wire	Inspect wiring and repair/replace as necessary.

Issues with Vehicle Park Signal

Condition	Cause	Correction
System will start up but won't level when parked	No park signal to controller	Inspect wiring and repair/replace as necessary.
	Park sensor malfunction	Inspect and replace per OEM service manual.
System levels when stopped and not in park	Park signal always on	Inspect wiring and repair/replace as necessary.
	Park sensor malfunction	Inspect and replace per OEM service manual.
Intermittent leveling when stopped in or out of park	Loose connector / wire	Inspect wiring and repair/replace as necessary.

Issues with Driver Interface

Condition	Cause	Correction
Warning light blinks, system appears to level.	CAN wires crossed or not connected.	Inspect wiring and repair/replace as necessary.
	Malfunctioning Driver Interface	Inspect and replace as necessary.
Warning light blinks, system does not appear to operate (level)	No power to ECU (5A 18ga Red Wire)	Inspect wiring and repair/replace as necessary.
	No ignition signal to ECU (Yellow Wire)	Inspect wiring and repair/replace as necessary.
	CAN wires crossed or not connected.	Inspect wiring and repair/replace as necessary.

Issues with Power Module

Condition	Cause	Correction
Pump exhibits high pitch whine immediately after pump stops or when vehicle lowering	The Check Valve is stuck open	Replace Power Module
Pump running under heavy load and leveling slow	The Check Valve is only partially open	Replace Power Module
Pump running under heavy load and no leveling	The Check valve is stuck closed	Replace Power Module
Hydraulic fluid leaking from Power Module	O-ring failure	Replace O-ring
	Manifold cracked	Replace Power Module
	Fitting loose	Tighten fittings
	Valve loose	Tighten valves to correct torque
	Bolts between manifolds loose/broken	Replace and /or tighten bolts to correct torque
	Hydraulic line loose	Tighten hydraulic line correctly
	Bolts between reservoir and manifold loose/broken	Replace and/or tighten bolts to required torque
	Broken / cracked reservoir	Replace reservoir

Issues with Strut Assembly

Condition	Cause	Correction
Hydraulic Leak	Weld failure between cylinder and end	Replace strut
	Cylinder fracture	Replace strut
	Threads stripped between cylinder and gland	Replace strut
	Seals worn out	Replace strut
	Rod severely scratched or dented	Replace strut
	Fitting loose	Tighten or replace fittings
	Hose failure	Replace failed hose
	Hose cut	Replace failed hose
Rod broken at bushing housing	Weld failure	Replace strut
Rod doesn't move freely in/out cylinder	Piston jammed in cylinder	Replace strut
Rod moves very easily in/out cylinder	Piston broken therefore no damping	Replace strut
Reduced damping level	Damping components broken/worn out	Replace strut
Strut upper mount not securely attached to frame or Strut	Bolts attaching bracket to frame broken / came out	Replace bolts and tighten to required torque
	Bolt attaching strut to bracket broke / came out	Replace bolts and tighten to required torque
	Weld Failure	Replace strut upper mount
	Structural failure	Replace strut upper mount
Strut lower mount not securely attached to axle or strut	Bolts attaching bracket to axle broken / came out	Replace bolts and tighten to required torque
	Bolt attaching strut to bracket broke / came out	Replace bolts and tighten to required torque
	Weld Failure	Replace strut lower mount
	Structural failure	Replace strut lower mount

Issues with Secondary Volume Assembly

Condition	Cause	Correction
Hydraulic Leak	Weld failure between tube and end	Replace secondary volume welded assembly
	Weld failure between tube and manifold	Replace secondary volume welded assembly
	Cylinder fracture	Replace secondary volume welded assembly
	Bleed screw loose	Tighten bleed screws to appropriate torque
	Fitting loose	Tighten all fittings
	Hose failure	Replace failed hose
	Hose cut	Replace failed hose
loose or no longer attached	Bolts attaching bracket to frame broken / came out	Replace bolts and tighten to required torque
	Bolt attaching volumes to bracket broke / came out	Replace bolts and tighten to required torque
	Weld Failure	Replace brackets
	Structural failure	Replace brackets

Parts List Information

Abbreviations

HCS Hex Cap Screw

HFB Hex Flange Bolt

SHCS Socket Head Cap Screw

SFHS Serrated Flange Hex Screw

HN Hex Nut, Non-locking

LHN Locking Hex Nut

LFN Locking Flange Nut

CHN Castle Hex Nut

HTCN Hex Thin Castle Nut

HFW Hardened Flat Washer

SLW Spring Lock Washer

SAE SAE O-Ring Fitting


37° SAE or JIC 37° Flare Fitting

LH Left Handed Part


RH Right Handed Part

Part Identification

Steering Sensor Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10591-001	Ball Stud, 10mm x 5/16-18
2	2	10006-011	HFW 5/16 .688 x .344 x .065 Z
3	1	10587-002	Asy, Linkage
4	1	10733-001	Wldmnt, Steering Linkage Mount
5	1	10741-001	Wldmnt, Steering Sensor
6	1	10586-002	Asy, Steering Sensor
7	1	10669-002	U-Bolt, 1/4-20 x 2.438 x 1.438 Gr 2 SQ
8	2	10238-002	HCS .313-18x1, Gr. 8, Zinc
9	2	10004-024	LHN 1/4-20, Gr. 2, Z Cntrlck




Power Module Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10941-011	Asy, Power Module F550
2	1	11111	Kit, Power Module Mounting
3	1	10614-001	Cap, Filler/Breather



Step 1: Attach Mounting Brackets to Power Module


- Torque 3/8-16 Bolts to 39 ft-lbs
- When Tightening reservoir screws, **Do Not Over Tighten**
- Install 90° fittings, Torque to 12 ft-lbs
- Install M5 Fasteners, Torque to 55 in-lbs




ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10799-014	Manifold Mount
2	1	10798-014	Reservoir Mount
3	2	10502-005	HFB M5-0.8x12 CL 10.9 BO
4	2	10805-004	Grommet, .19 ID x .56 OD x .375 T
5	2	10088-001	FW #10
6	2	10510-002	STS #10-16 x .750, Z, Hex Head
7	2	10252-003	SFHS 3/8-16 x .625, Gr 8.2
8	2	10322-021	Hyd Fit 90, -4 37 x -4 37 F
9	1	10865-004	J-Bolt, 3/8-16 x 6"L
10	1	10865-003	J-Bolt, 3/8-16 x 4"L
11	3	10012-011	LFN 3/8-16, Gr. G, Nylon Top
12	1	10501-002	HFB 3/8-16 x 1.250, Gr 8

Step 2: Attach Power Module to Frame


- Torque 3/8 J-Bolt nuts to 28 ft-lbs
- Torque 3/8 Nut/Bolt to 39 ft-lbs




Front Hanger Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10730-001	Asy, Front Hanger, LH
2	1	10729-002	Wldmnt, Front Hanger, RH
3	8	10012-008	LFN 5/8-11 Gr G, Black Phos
4	8	10874-175	HFB 5/8-11x1.750, Gr. 8, B.O




Height Sensor Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	2	10586-001	Asy, Height Sensor
2	2	10591-001	Ball Stud, 10mm x 5/16-18
3	10	10006-011	HFW 5/16 .688 x .344 x .065 Z
4	6	10004-021	LHN 5/16-18 Gr C Z
5	2	10587-001	Asy, Linkage
6	4	10238-004	HCS 5/16-18x1.250 Gr 8 Z




Axle Clamp Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	6	10006-007	HFW 1/2 Z
2	2	10004-019	LHN 1/2-13, Gr. C, Z
3	2	10744-001	Weldment, Axle Cradle
4	1	10745-001	Weldment, Axle Seat LH
5	4	10064-003	U-Bolt 3/4-16 x 14.63 Tri-8
6	1	10745-002	Weldment, Axle Seat RH
7	2	10011-008	HCS 1/2-13x1.500, Gr. 8, Zinc
8	2	10011-012	HCS 1/2-13x5.000, Gr. 8, Z
9	8	10012-012	LFN 3/4-16, Gr. G, Black Phos









Bridge Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10762-001	Weldment, Bridge
2	2	10064-002	U-Bolt, 5/8-18 x 8.5 x 8.0, Slanted
3	1	10786-001	Asy, Track Rod
4	8	10006-007	HFW 1/2 Z
5	4	10004-019	LHN 1/2-13, Gr. C, Z
6	1	10789-001	Wldmnt, Track Rod Mnt
7	2	10006-009	HFW 1/4, .625x.281x.064, Z
8	1	10004-013	LHN .250-20, Gr. C, Zinc
9	1	10210-004	HCS 1/4-20x1.000 Gr. 8, Z
10	4	10011-013	HCS 1/2-13x2.000, Gr. 8, Z
11	6	10012-008	LFN 5/8-11 Gr G, Black Phos
12	1	10874-375	HFB 5/8-11x3.750, Gr. 8, BO
13	1	10874-400	HFB 5/8-11x4.00, Gr. 8, BO
14	4	10874-175	HFB 5/8-11x1.750, Gr. 8, BO
15	4	10012-013	LFN 5/8-18, Gr. G, Black Phos



Control Arm Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	2	10777-003	Asy, Control Arm, Upper
2	1	10777-001	Asy, Control Arm, LH, Lower
3	1	10777-002	Asy, Control Arm, RH, Lower
4	8	10006-004	HFW 1.000, Zinc
5	8	10012-003	LPN 1-8, Gr G, Z Top Lock
6	8	10003-003	HB 1.000-8x6.000, Gr. 8, Zinc




Strut Components				
ITEM NO.	QTY.	PART NUMBER DS137F-A	PART NUMBER DS147F-B2	DESCRIPTION
1	4	10006-004		HFW 1.000, Zinc
2	4	10012-003		LFN 1-8, Gr. G, Z Top Lock
3	2	10003-004		HCS 1-8 x 7.000, Gr. 8, ZY
4	2	10003-008		HCS 1-8 x 5.000, Gr. 8, ZY
5	2	10640-002		Bearing Spacer, 1.25 x 1.02 x .318
6	2	10640-003		Bearing Spacer, 1.25 x 1.02 x .1068
7	1	10838-001	10801-001	Asy Strut, Port Right
8	1	10838-002	10801-002	Asy, Strut, Port Left




DS137F-A Only

Secondary Volume Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	4	10843-003	T-Bolt Clamp, Range 4.88-5.5
2	16	10006-010	HFW 3/8 .813x.406x.065, Z
3	8	10004-016	LHN 3/8-16, Gr. 8, Z
4	4	10830-013	Wldmnt, Volume Mount, Bolt-on
5	8	10461-005	HCS 3/8-16x1.500, Gr 8, Z
6	1	10597-021	Asy, 2nd Vol 50 x 450, LH
7	1	10597-022	Asy, 2nd Vol 50 x 450, RH




DS147F-B2 Only


Secondary Volume Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	4	10843-003	T-Bolt Clamp, Range 4.88-5.5
2	16	10006-010	HFW 3/8 .813x.406x.065, Z
3	8	10004-016	LHN 3/8-16, Gr. 8, Z
4	4	10830-013	Wldmnt. Volume Mount, Bolt-on
5	8	10461-005	HCS 3/8-16x1.500, Gr 8, Z
6	1	10597-013	Asy, 2nd Vol 108 x 539, LH
7	1	10597-014	Asy, 2nd Vol 108 x 539, RH
8	1	10675-009	Asy, Hose, -4 x 129-7/8"L
9	1	10675-010	Asy, Hose, -4 x 176-1/2"L




Jounce Bumper Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	2	10871-001	SLW M10, Z
2	2	10502-004	HFB M10-1.5 x 35 CL 10.9 Z
3	2	10867-003	Jounce Bumper, 2.375"Dia x 3.00"T




Bumper Pad Components			
ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10772-001	Wldmnt, Bumper Pad, LH
2	2	10006-007	HFW 1/2 Z
3	1	10772-002	Wldmnt, Bumper Pad, RH
4	2	10011-008	HCS 1/2-13x1.500, Gr. 8, Zinc




Dash Harness Schematic



2014 and Newer







LiquidSpring™ LLC

4899 E 400 S
Lafayette, IN 47905

Phone: 765-474-7816

Fax: 765-474-7826

Web: www.liquidspring.com

Information contained in this publication is subject to change without notice or liability. LiquidSpring LLC reserves the right to revise the information presented or discontinue the production of parts described at any time.